

# Setare canale de comunicare Scanner XL 9300

**Pasul 1.** Revenirea parametrilor la forma initiala de fabricatie.



Reveniure La Setarile Din Fabricatie


**Pasul 2.** Interfata de comunicare cu calculatorul. (obligatoriu seriala)



Interfata Seriala

**Pasul 3.** Anulare (resetare) canale. Aceasta setare se face pentru a aduce receiver-ul la forma initial "00". Folosind aceasta setare toate canalele programate anterior se se vor anula.

3.1



X L - D C -




0

3.2-----se citesc ambele-----



0

3.3



X L % E D %

**Pasul 4.** Inregistrare canal. (exemplu 0-1).

4.1




X L + R G +

4.2



0

-----se citesc ambele-----



1

4.3



4.4



4.5



-----se citesc ambele-----



4.6



Pentru a conecta al doilea Scanner se repeta pasul 4 schimbând canalul de la 0-1 la 0-2 , exemplu pentru canalul 0- 2 se va citi :













-----se citesc ambele-----



Practic se inlocuieste codul de bare 1 cu codul de bare 2 .

**Atentie!!! Nu se va relua pasul 3 deoarece receiver-ul se va reseta la forma initiala 0-0.**

Tabel Canale:

0	 0	1	 1
2	 2	3	 3
4	 4	5	 5
6	 6	7	 7
8	 8	9	 9